

**Important information!**  
 If your iPad runs iOS 5, adjust 2 settings to block users leaving the running website/app:  
 1. Settings > General > Multitasking Gestures **must be deactivated**  
 2. Settings > Notifications > Notification Center: **remove all listed apps**

# instructions / infoport v1



- 1. Prepare iPad:** for example deactivate sleep function and ambient light sensor, install apps.  
  
Recommendation for public use (to reduce risk of scratches, fingerprints, glare): Apply a mat, anti-fingerprint screen protector on iPad.



- 2. info port:** slide out drawer (to the left or to the right side).
- 3. For mobile use:** At the info port feet, press in the 4 supplied rubber feet with a screwing-like movement.  
  
**For a fix installation:** Screw on the outer frame of info port.



- 4. Recommendation for a fix installation with power cable: \***  
The iPad cable best exits the surface at the *flatter* foot of info port.  
The cable part exiting the surface must be 355mm long (without connector head), so that the drawer with iPad can be opened/closed later easily.




- 5. Prepare drawer for iPad:**  
Tape protectors *at the top* of 8 iPad holders: *thin* for iPad 1, *thick* for iPad 2 and iPad 3. \*\*  
Place mat(s) into drawer: *thin* mat for iPad 1, *both* mats for iPad 2, *thick* mat for iPad 3.  
Place drawer with higher side on the back (will later be inserted at the higher info port foot). Place iPad into drawer, iPad home button on the *right\** side.



- 6. Slide drawer carefully in outer frame:**  
Slide drawer into frame until the small slot on the bottom of the drawer is close to - but not below - the outer frame.  
Insert iPad cable into the slot, and connect the cable to the iPad.  
Slide the rest of the drawer in, until it's centered below the outer frame.



- 7. Securing drawer and iPad:**  
Use a padlock with shackle thickness of 4mm to secure the iPad.  
For private use, also the supplied S-hook can be inserted to prevent opening of the drawer.



- 8. Handling**  
Access all functions from below.  
① power button ② rotation lock/volume (configure in iPad settings!)

- 8. Opening the drawer:**  
Carefully slide out the tray, until the slot with the inserted iPad cable is visible.  
Disconnect cable from iPad and remove it from slot, then slide out drawer completely.

### Software tips

- xStand: iPad app with fullscreen mode, remote configuration of multiple iPads via Mac
- AVD Browse: iPadd app with fullscreen mode and other useful webkiosk functions
- MyKiosk: iPad app with full screen mode, adds navigation buttons to existing webpage

\* Standard installation. There are other ways to install, depending the situation/needs.  
 \*\* Option: use always same tape protectors for iPad and iPad 2/iPad 3, insted adjust by carefully bending holders with a monkey wrench.